

VEHICLE IDENTIFICATION. (Chassis Numbering)

Commencing at the 1st. of January 1970, a new format has been used for Vehicle Identification.

An example of a new chassis number is given below, together with the full identification breakdown.

7001.010001 E	Both chassis and body numbers being the same
7001.	Denotes year and month of manufacture (1970, January)
01	Denotes the production batch
0001	Denotes the chassis number
E	Denotes the model

As there are at present 16 different model types, the following codes will be used for model identification.

Elan STD	Coupe	G.Britain & N. Ireland	A
Elan STD	Coupe	Export	B
Elan STD	Convertible	G.Britain & N.Ireland	C
Elan STD	Convertible	Export	D
Elan S/E	Coupe	G. Britain & N.Ireland	E
Elan S/E	Coupe	Export	F
Elan S/E	Convertible	G.Britain & N.Ireland	G
Elan S/E	Convertible	Export	H
Elan Federal	Coupe	Export	J
Elan Federal	Convertible	Export	K
Elan +2'S'		G. Britain & N.Ireland	L
Elan +2'S'		Export	M
Elan +2'S' Federal		Export	N
Europa		G.Britain & N.Ireland	P
Europa		Export	Q
Europa Federal		Export	R

**NOTE:**

Commencing at 1st. January 1972, the 'Batch No.' is no longer used.

7201	Denotes year and month of manufacture (1972, January)
0001	Denotes the chassis number
E	Denotes the model